PhoneWatch Home Safety System - Quick Guide

Arming	Press + 4 Figure code or KEYTAG, This arms the entire system **(Away)** Press + 4 Figure code or KEYTAG, Arms part of the system **(Home)** *** KEYTAG - place the keytag over the number 8**
Disarming	Enter a valid user code or use keytag (place keytag over the number 8). The keypad then gives a disarmed tone and green light goes out
Indicator Lights	The keypad has indicator lights to show the current status of the alarm system
Light 1 "SYSTEM ARMED"	**ALIGHT:** The entire system is armed (away) **BLINKING SLOWLY:** Part of the system is armed (Home) **OFF:** System is disarmed
Light 2 "SYSTEM FAULT"	**ALIGHT:** There is a fault in the system (batteries, power, gsm). If this light stays on contact PhoneWatch **BLINKING SLOWLY:** Fault is registered in system memory needs to be reset **OFF:** No Fault
Light 3 "ALARM ACTIVATED"	**ALIGHT:** The alarm has been activated. This includes opening a door contact and being in sight of a motion sensor **BLINKING SLOWLY:** There is an alarm activation registered in the Memory **OFF:** No alarm activation
Light 4 "SENSOR/PANEL TAMPER WARNING"	**ALIGHT:** There is an issue with a sensor/panel **BLINKING SLOWLY:** There is a fault registered in the system Memory, needs to be reset **OFF:** No sensor warning

PhoneWatch Home Safety System - Quick Guide

KEYPAD TONES

Each time you set your alarm panel you will hear a series beeps prior to the arming tone.

Arming - On arming one beep per second
Arming on the away function: the beeps continue until the outer door is closed
Arming on the home function: the beeps continue for 30 seconds until the system is armed

Disarming - Long, continuous beep
The duration of this beep is about 2.5 seconds. This confirms that the system has been properly disarmed

Entry delay - On entry one beep per second
This entry delay continues for 20 seconds* after you have opened the outer door. You must disarm the system within this time. Please note The entry beeps wont start beeping immediately when entering but the delay you have to get to the panel to disarm it will start straight away

Fault - 7 rapid beeps followed by 7 more
This indicates a fault in the system

Alert - 4 beeps in the event of alarm activation sent via keypad
Confirms the transmission of an alarm activation to PhoneWatch

Please ensure you close all interior and exterior doors and windows before setting your alarm

To view full user manual visit phonewatch.ie/uploads/manual.pdf

Call us on **1850 753 753** or chat online at **phonewatch.ie/customer-support**

PHONE WATCH

Your safety. Our passion.